



NOTES:

1. DO NOT ATTACH DUCT TO TOP OF LOWER LOUVER BLADE AS TYPICAL. THIS CREATES SEALING PROBLEMS AT MULLIANS AND OTHER VERTICAL MEMBERS.
2. CONSTRUCT SLEEVE AND DUCTWORK TO SUPPORT WEIGHT OF SERVICE TECHNICIAN.
3. SEAL ALL JOINTS WATER TIGHT AT BOTTOM OF DUCT AND SLEEVE.
4. INSULATE DUCT AND SLEEVE AS SPECIFIED.

NOTE TO A/E:
 INDICATE WORK TO BE DONE BY GENERAL CONTRACTOR AND VENT CONTRACTOR.



LOUVER INSTALLATION DETAIL

NOT TO SCALE

23 37 00-1

LOUVER INSTALLATION DETAIL

Date: August 19, 2010

Dwg. No.: 23 37 00-1