



**NOTES:**

1. DO NOT ATTACH DUCT TO TOP OF LOWER LOUVER BLADE AS TYPICAL. THIS CREATES SEALING PROBLEMS AT MULLIANS AND OTHER VERTICAL MEMBERS.
2. CONSTRUCT SLEEVE AND DUCTWORK TO SUPPORT WEIGHT OF SERVICE TECHNICIAN.
3. SEAL JOINT BETWEEN DUCT AND SLEEVE WATER TIGHT ALL AROUND.
4. INSULATE DUCT AND SLEEVE AS SPECIFIED.

**NOTE TO A/E:**  
 INDICATE WORK TO BE DONE BY GENERAL CONTRACTOR AND VENT CONTRACTOR.



# LOUVER INSTALLATION DETAIL

NOT TO SCALE

23 37 00-01

0	8/19/10	ORIGINAL ISSUE
#	DATE	REVISION DESCRIPTION

Date: June 15, 2013

Dwg. No.: 23 37 00-01

LOUVER INSTALLATION DETAIL