



**NOTES:**

1. TO ATTACH FLEX DUCT TO THE HARD DUCT, TAPE THE INNER LINER TO THE HARD DUCT THEN ATTACH WITH TWO NYLON TIE WRAPS; ONE FOR THE INNER LINER AND ONE FOR THE OUTER SHELL. FOLD THE OUTER SHELL INSIDE ITSELF SO IT HAS NEAT EDGES PRIOR TO TIE WRAPPING.
2. "FLEXFLOW" ELBOW IS AN ACCEPTABLE PRODUCT FOR RADIUS FORMING ELBOW (1-800-459-4822).



# DIFFUSER CONNECTION DETAIL

NOT TO SCALE

23 37 13-1

DIFFUSER CONNECTION DETAIL

Date: June 15, 2013

Dwg. No.: 23 37 13-1